

OVEN FRAME REMOVAL & INSTALLATION



TO REMOVE:	TO INSTALL:
<ul style="list-style-type: none">- Use 4mm Allen wrench to "unhook each connector biscuit (ill. 1)- Remove the frame (ill. 2)	<ul style="list-style-type: none">- Place frame onto the cabinet (ill. 2)- pay attention to reveals- ensure that all biscuits line up- Use 4mm Allen wrench to tighten all the connector biscuits (ill.1)
<p><u>Wood biscuits to be used if:</u></p> <ul style="list-style-type: none">- Frame with a side reveal that is more than 1/16"- Stile is too narrow (stile width differs by material)- Inset frame	

