

TIP-ON BLUMOTION FOR LEGRABOX TROUBLESHOOTING



GENERAL INSPECTION:

- Make sure cabinet is square and that the Tip-On Blumotion components are installed correctly / not damaged
- Remove any obstacles
- Ensure no front bumpers are installed; these will inhibit the function of Tip-On Blumotion when the front is pressed
- Ensure that the front gap is the same on each side, adjust if necessary
- Make sure that synchronization for Tip-On is installed correctly
- Ensure that cabinets 35.43" wide or wider have side stabilizers installed for additional stabilization

*For more details please consult your Customer Solutions Representative

Sample Problems and Solutions

Drawer does not open, or does not open far enough

- Remove bumpers
- Remove any obstacle
- Ensure front gap is the same on each side
- Make sure cabinet is square, not damaged

Drawer opens on its own, completely or only on one side

- Ensure that the synchronization set is installed correctly
- Replace Tip-On Blumotion unit if it's damaged or defective
- Ensure front gap is the same on each side

Tip-On Blumotion unit(s) "clicks" loudly when activated

- Make sure that the track setback is the same on both sides
- Ensure that tracks are not installed at different heights or angles (parallel installation only)
- Ensure front gap is the same on each side

Drawer remains in open position, but can be closed by hand (remains 1" from full closed position)

- Replace Tip-On Blumotion unit(s) if control unit is bent or control link is broken